

# Contents

FOR YOUR SAFETY .....	1
INTRODUCTION .....	2
SPECIFICATIONS.....	2
INSTALLATION .....	2
Package contents.....	2
Connecting the microphone.....	2
Use with the PC .....	3
Use with the PlayStation® 4 .....	3
INSTRUCTIONS FOR USE.....	3
The controls.....	3
PROBLEMS AND SOLUTIONS .....	4
CONTACT AND SUPPORT .....	4
WARRANTY CONDITIONS .....	5
DISPOSAL OF OLD EQUIPMENT & BATTERIES .....	5

## FOR YOUR SAFETY

- Please read this manual carefully before operating the snakebyte python 3300S headset and take into account all the information and tips included. Keep these instructions in a safe place so that you can refer to them again later.
- To avoid invalidating the snakebyte guarantee and warranty, you should not disassemble your snakebyte python 3300S headset – the device contains no user-serviceable components, inside or out. Improper handling will void the warranty in 100% of cases and could render the device inoperable. Repairs should therefore be carried out exclusively by qualified service personnel.
- Keep the snakebyte python 3300S headset away from vessels containing liquids such as vases, bottles, bathtubs, swimming pools, hot tubs, etc. Potential fatal injury aside, all defects resulting from contact with liquids are excluded from the guarantee.
- **WARNING:** Continued use of headphones at high volume causes irreparable hearing damage. Reduce the volume to the necessary minimum and take regular breaks. It is recommended to set the headset to the lowest volume, and then gently increase it to the desired volume level.

## INTRODUCTION

### Thank you!

Congratulations on your purchase of the snakebyte python 3300S headset. We appreciate your trust in our products. This product has been made with special care by qualified personnel and under continuous quality control. We hope you enjoy it.

This guide makes getting started with and using the python 3300S headset really simple. Should you still have questions pertaining to the installation and usage of the device beyond the contents of this manual, please contact your local dealer or our friendly customer support at [support@mynakebyte.com](mailto:support@mynakebyte.com).

## SPECIFICATIONS

- PC stereo headset with analog Input via 2x 3.5mm stereo jacks
- Also compatible with the PlayStation® 4 (requires adapter cable, available separately) or any playback device with a 3.5mm jack port
- Powerful 50mm drivers for great sound with clear highs and powerful bass – suitable for the playback of games, films and music.
- Extended wearing comfort thanks to soft memory foam ear pads and adjustable, padded headband
- Detachable omni-directional microphone allows for flexible use - at home or on the road - as a headset or just as headphones
- Controller integrated into the connection cable for convenient volume control and muting the microphone (total cable length approx. 3 m)
- Technical details:
  - Frequency range: 20 Hz – 20 kHz
  - Impedance: 32 ohms
  - Speakers: 50mm
  - 90dB+/-3dB at 1mW, 1KHz
  - Microphone sensitivity: (1 KHz), -38 dB

Changes to technical details reserved.

## INSTALLATION

### Package contents



The snakebyte python 3300S packaging should contain the following:

- 1x python 3300S headset
- 1x this manual

If any parts are missing or clearly broken, please contact your dealer immediately.

### Connecting the microphone

When connecting the microphone, ensure that the dots highlighted in the figure are aligned and are positioned on top of each other before plugging in the microphone and turning it 90° counterclockwise.



### **Use with the PC**

Connect the headset to the audio ports on your PC or your sound card. The connectors are color-coded (green = speaker, pink = microphone). Make sure that the correct input and output devices are enabled in the Control Panel. The headset is ready to use immediately.

### **Use with the PlayStation® 4**

A separately available adapter cable is required for use with the PlayStation® 4 (2x jack plug (tripolar) -> 1x plug (quadripolar)). Connect the headset with the appropriate adapter to the Dual Shock® 4 controller. The output of game and chat sounds via the headset requires to change settings in the console's menu. Navigate to "Settings - Sound and Screen - Audio Output Settings - Output to Headphones", and select "All Audio".

Even though the python 3300S headset has an integrated volume control, you can change basic settings on the console here: "Settings - Devices - Audio Devices". Adjust the output volume of the console as required, as well as the microphone level.


## **INSTRUCTIONS FOR USE**

### **The controls**

The control adapter integrated into the cable offers the following controls:

1. Volume +/-

## 2. Microphone mute On/Off



## PROBLEMS AND SOLUTIONS

If you experience problems when using the snakebyte python 3300S, please read the following section on potential error sources carefully before contacting customer service or your dealer.

### 1. My python 3300S does not work.

- If you are trying to use the headset with the PlayStation® 4 console, please check the console's system settings. The output volume might be turned down on the software side, or the audio output set incorrectly.
- Try to isolate the problem. Use the headset with a different signal source to define the exact cause of the problem.

## CONTACT AND SUPPORT

For problems that cannot be solved using the above-mentioned approaches, please contact us at the following address:

snakebyte Europe GmbH  
Konrad-Zuse-Str. 13  
58239 Schwerte  
Germany

<http://www.mysnakebyte.com>  
[support@mysnakebyte.com](mailto:support@mysnakebyte.com)

## **WARRANTY CONDITIONS**

You are entitled to a warranty of two years after purchase of the snakebyte python 3300S. Please therefore store your invoice or sales receipt together with this manual.

In order to safeguard your warranty and to protect your health, you should not attempt to carry out repairs to the unit independently. The python 3300S contains no parts that can be serviced or repaired by the user. This will also avoid the risk of electric shock or even fire.

The warranty only covers defective components and defects in workmanship that occurred during the manufacturing of the python 3300S.

The following defects are therefore not covered by the warranty:

- all damages arising from the failure to observe these instructions
- defects caused by improper use or cleaning
- mechanical and optical damage (e.g. scratches, broken casing caused for example by the use of violence of any kind or gross negligence)
- damage due to force majeure
- defects caused by the connected components that are not shipped with the python 3300S

## **DISPOSAL OF OLD EQUIPMENT & BATTERIES**

Please do not dispose of defective devices in your household waste, but take them to a recycling plant, which guarantees the environmentally friendly recycling of the materials contained in accordance with EU Directive 2002/96/EC of the European Parliament.

Furthermore, we as the manufacturer are required by law in accordance with the Battery Directive to inform you as the consumer of the following:

You are legally obliged to return the batteries included in the contents of this package. After use, you can return them to snakebyte Europe, a municipal collection point or the dealer.

Batteries containing pollutants are marked with a crossed-out trash can and the chemical symbol (Cd, Hg, or Pb) of the heavy metal which is crucial for determining the battery's toxicity.

Protect and preserve the environment, do not dispose of used batteries in your household waste.