



snakebyte

UPDATE

GAME:PAD S PRO™

Switch Controller Update Instructions


GAME:PAD S PRO™

Switch Controller Update Instructions

(ENGLISH)

STEP 1

Download the updater from the support section of the snakebyte website and open it.




STEP 2

Press and hold the "+" button of your controller, then connect it to a USB port of your PC via a USB cable.

The second LED indicator on the controller lights up.


STEP 3

Press the "Start" button of the updater. The update process begins and the third and fourth LED indicators on your controller light up.



STEP 4


Wait until the progress bar is completely full.



STEP 5

A "Download successful!" message will pop up and **all four LED indicators start flashing.**

Attention: If the four LED indicators do not flash, do not remove the USB cable! Retry the update by pressing "Start" a second time. Failing to follow this step can break the controller!



STEP 6

Remove the USB cable after the update is completed and **the four LED indicators are off.**

